

**Water Samples**

**Every container must have a label and custody seals.** If sampler is **NOT** using tags (tie-on, paper - Tyvek tags) they will create in SCRIBE a label (waterproof) that will contain, at minimum, the following information:

- 1) Case number
- 2) CLP sample number
- 3) Station location
- 4) Preservative used
- 5) Analysis

Every container will have this label, if tags are not used.

**You must customize the bottle label in SCRIBE and also the analysis. Please contact the SCRIBE helpdesk (800/999-6990), if you need assistance. Bubble wrap bottles and place in zip lock bags.**  
**The turnaround time is 21 days.**

**LVOA analysis by SOM01.2**



Sample=

**3 x 40 ml VOA vials  
per station location**

**Lab QC** – These are field QC (trip blanks) and do not require lab QC

**Preservative** = Preserve to a pH of 2 with HCl and cool to  $\leq 6^{\circ}\text{C}$ , but not frozen, immediately after collection. DO NOT FREEZE water samples.

**SVOA-SVOASIM (SV/SVSIM) – 4 x 1 liter amber glass bottles per station location**

Sample Only =



**Preservative** = Cool all samples to  $\leq 6^{\circ}\text{C}$ , but not frozen, immediately after collection. DO NOT FREEZE water samples.

**Lab QC** – These are field QC samples and do not require lab QC